

PN 1100471

1971-72 CHEVELLE SEQUENTIAL LED TAIL LIGHT KIT INSTALLATION TEMPLATE

1. Cut template along outline and place template inside of the housing.
2. Align line to center with the socket hole in housing.
3. Mark the hole centers and drill using a 5/32 size drill bit.
4. Use same template for both sides.

